

Fig. 1

PRIOR ART





Fig. 2

PRIOR ART



PRIOR ART

Fig. 3A





Fig. 3B



PRIOR ART

Fig. 4




Fig. 5




Fig. 6




Fig. 7A




Fig. 7B




Fig. 8




Fig. 9




Fig. 10




Fig. 11




Fig. 12




Fig. 13




Fig. 14







Fig. 15



A horizontal number line with open circles at 150 and 160. A solid black dot is placed between them, with a curved line pointing to it from the number 76.




Fig. 17












Fig. 18







Fig. 19




19-1



19-2



19-3



19-4




Fig. 20




Fig. 21




Fig. 22




Fig. 23




Fig. 24





Fig. 25



Voltage Control Circuitry1 (90)

→ Basic Switching PAM




Fig. 26A

Voltage Control Circuitry2 (95)

→ Bias Modulated PAM




Fig. 26B

Fig. 27

Augmented voltage Control Circuitry2 (95) for Bias Modulated PAM





Fig. 28

Examples of Driver stage Control Circuitry (96)



28-1








Fig. 30




Fig. 31




Fig. 32




Fig. 33

